

NOTES-
THIS DWG 286-506A PULLEY INSTALL
REPLACES 286-1033 PULLEY INSTALL
FOR FBY-5 AIRPLANES AS NOTED BELOW
SEE 286-1033 FOR INSTALLATION
DETAILS NOT SHOWN ON THIS DWG
DRILL #10(193) FOR AN3 BOLTS

[illegible]